

OREGON

POWERsharp®

DIAMOND



<b>ALKO</b>	BKS35/35 II 526, AC3107 14, AC3107 16, BKS35/35, BKS38/40, BKS42, KB38/40	542308	PS45E	542310 542313	PS52E PS49E	542314 542316	PS56E PS54E
<b>ALPINA</b>	P371					542315	PS56E
<b>CUB CADET</b>	CC1936, CC2740			542312	PS52E	542317	PS56E
<b>DOLMAR</b>	100, 340, 341, PS-3410, PS-3410TH, PS-350C	542308	PS45E	542310	PS52E	542314	PS56E
<b>DRAPER</b>	EXPERT 37CC			542310	PS52E	542314	PS56E
<b>ECHO</b>	CS2100, CS230T, CS230TES, CS260TES, CS270WES, CS3000, CS3050, CS310, CS330T, CS330MX4, CS3400, CS341, CS350TES, CS3500, CS3501, CS350WES, CS351WES, CS360T, CS370, CS370ESCS-1800, 4200ES, CS420ES	542308	PS45E	542310	PS52E	542314	PS56E
<b>EFCO</b>	132S, 136, 137, MT350, MT3500, MT370, MT3700	542308	PS45E	542310	PS52E	542314	PS56E
<b>EINHELL</b>	BKS38-35, MKS1940, MKS38/41, MKS35/35, MKS42/45, RBK1440			542313	PS49E	542316	PS54E
	BG-EC2040, BG-PC3735, BG-PC4040, EK1535, EK1540, EKS1840, EKS2040P, KSE1435, KSE1640, KSE2000, KSE2040WK, PEK1840, PES1540, PES1640, PES2000, PES30/2, PES34/2, PES34/3, PES35, PES35/2TS, PES35/3, PES35/3TS, PES40/3, PKS1635, PKS1840, PKS2040WK, PKS35/1AV, PKS40/1AV, RBC4640, RBK3735, RBK4040, REK1840, REK2040WK, PROFI	542308	PS45E	542310	PS52E	542314	PS56E
<b>GRIZZLY</b>	EKS 1700, EKS 1700-40, EKS 1800, EKS 1800-40, EKS 2000, EKS2000QT, EKS2500/5, EKS2500/5QT, PKS2000/4, PKS40, PKS40/3			542313	PS49E	542316	PS55E
<b>HANDY</b>	THC38, THC45			542310	PS52E	542314	PS56E
<b>HOMELITE</b>	HCS3435BA HCS3840BA			542310	PS52E	542314	PS56E
<b>HORNBACH</b>	EK1600, MKS3840					542314	PS56E
<b>HUSQVARNA</b>	36, 41, 136, 137, 141, 142, 235, 236, 236E, 240, 240E, 334, 334T, 335XPT, 338XPT, 339XP, T435			542312	PS52E	542317	PS56E



OREGON

POWERsharp®

DIAMOND



3-5" SEC



<b>IKRA/ALDI/LIDL</b>	EKS1700, KSB3940, KSE2000, KSE2400-40, KSI2000, KSI2000-40							542314	PS56E
<b>IKRA: HELLWEG</b>	KSE2400, KK19-40							542314	PS56E
<b>JONSERED</b>	CS2138S							542317	PS56E
<b>MACALLISTER</b>	MAC2000W, MAC2240							542314	PS56E
<b>MAKITA</b>	DCS230T, DCS34, DSC340, DCS3400TH, DCS3410TH, DCS3501, DCS400, DCS4301, DCS4610	542308	PS45E	542310	PS52E	542314	PS56E		
<b>MCCULLOCH</b>	MAC 4-18XT, 7-38, 7-42, 8-42, 445, 839, MAC335, MAC338, MAC435, MAC842			542310	PS52E	542314	PS56E	542316	PS56E
<b>MITOX</b>	3814, 4116			542310	PS52E				
<b>OLEO-MAC</b>	GS35, GS370, GS410C, GS940, 937, 941C			542310	PS52E	542314	PS56E		
<b>OBI/LUX</b>	CM12040KS, 2140KSE	542308	PS49E	542310	PS52E	542314	PS56E		
<b>PARKSIDE/ALDI</b>	EKS 1600, EKS 1800, EKS 2500/5, EKS 2500/5QT			542313	PS49E	542316	PS55E		
<b>PARTNER</b>	335, 338, 842, P738, P740, P842, FORMULA 60			542310	PS52E	542314	PS56E		
<b>PERFORMANCE POWER</b>	PP1800, PP40CCEPA2, PWR33CCCSA					542314	PS56E		
<b>RYOBI</b>	RCS3335, RCS3535CA, RCS3535A, RCS3540C, RCS4040CA, RCS4046			542310	PS52E	542314	PS56E		
<b>SANLI</b>	CS3740, CS4545					542314	PS56E		
<b>SHINDAIWA</b>	2855, 3525	542308	PS45E	542310	PS52E	542314	PS56E		
<b>SPEAR &amp; JACKSON</b>	SPJCS3740, SPJCS4040	542308	PS45E	542310	PS52E	542314	PS56E		
<b>SOLO</b>	613, 620, 614, 635	542308	PS45E	542310	PS52E	542314	PS56E	542317	PS56E
<b>STIHL</b>	009, 010, 015, 018, 020, 021, 023, MS170, MS170D, MS171, MS180, MS180CBE, MS181, MS181CBE, MS191, MS191T, MS192, MS192CBE, MS200T, MS210, MS210CBE, MS211, MS211CBE	542309	PS44E	542311	PS50E	542315	PS55E		
<b>TANAKA</b>	ECS3351, TCS2801S, TCS33EB	542308	PS45E	542310	PS52E	542314	PS56E		